

General instructions for cleaning and care

no. 40 Cement surface layer (rough)
























**cleaning system without treatment
end of construction**

object _____
address _____
room classification _____

date _____
customer _____
representative _____

work process: select one work stage from each number

cleaning method		* recommendations chemical products	dosage	* recommendations pad / brush / mop / cloth	recommendations machine / tool	comments
1	 dry vacuum cleaning			Dust roller nozzle Neverclog filter without ring Filter bag with ring	Twinvac / Duovac / Silento /	
1	 vacuum sweeping sweeping			Carpet set - Twister	Speedmatic Twister Turbo Sweep	large areas: <div>2 m</div>
2	 dusting damp mopping			B Masslinn 2000/Floorwit white B Multi squeegee/	Balit Varifix/ Balit/	
cleaning without maintenance care product (if coating follows)						
3	 wet mopping direct method	Ecofloor V Indumat V Antiwax forte	0.5 - 1% 2 - 5% 2 - 5%	Micro-Mop Top/ Microsol mop/	Socar / Drewell	
3	 scrubber drying direct method	Ecofloor V Reshine V Antiwax forte	0.5 - 1% 3 - 5% 2 - 5%	 Microsol fibre pad/  Pad blue/ S  Scrubbing brush Supernylon/	Duomatic / Laser Mambo / Samba Sprinter / iMatic	
3	 wet scrubbing and wet vacuuming	Ecofloor Antiwax forte Reshine	0.5 - 1% 2 - 5% 3 - 5%	 Microsol fibre pad/  Pad blue/ S  Scrubbing brush Supernylon/	Monomatic LS / Watertank Duovac /	heavily soiled  
cleaning with maintenance care (first protective treatment with same product as in maintenance cleaning)						
4	 wet mopping direct method	Redur Brill	3% 3 - 5%	Micro-Mop Top/ Microsol mop/ Flat mop/	Socar / Drewell	Brill should be used with flat mop only 
4	 scrubber drying direct method	Redur Brill	3% 3 - 5%	 Microsol fibre pad/  Pad blue/ S  Scrubbing brush Supernylon/	Duomatic / Laser Mambo / Samba Sprinter / iMatic	

* basic treatment / structure: B: coated / C: waxed / D: oiled / E: sealed / F: untreated / G: maintenance care product / P: polishing / S: structured / V: heavily soiled

General instructions for cleaning and care

no. 40 Cement surface layer (rough)



maintenance cleaning

object _____

date _____

















address _____

customer _____

work process: select one work stage from each number

room classification _____

representative _____

↓	cleaning method		frequency	recommendations chemical products	dosage	* recommendations pad / brush / mop / cloth	recommendations machine / tool	comments
1		dusting damp mopping	<input type="checkbox"/>			B Masslinn / Floorwit B Synthetic fur	Balit Varifix/ Balit/	
1		dry vacuum cleaning	<input type="checkbox"/>			S Dust roller nozzle	Monovac / Scuba	
1		vacuum sweeping sweeping	<input type="checkbox"/>			Carpet set - Twister	Speedmatic Twister Turbo Sweep	large areas: <input type="checkbox"/> 2 m
2		chewing gum removal	<input type="checkbox"/>	Karpfrost Karpotek	100%		Monovac / Scuba	if needed <input type="checkbox"/>
cleaning without maintenance								
3		wet mopping direct method	<input type="checkbox"/>	Ecofloor Reshine Alcosal	0.5 - 1% 1 - 2% 1 - 2%	Micro-Mop Top/ Mop Microbrush/ Mop Variwet	Wetbox system Socar / Drewell Variwet / B. Varifix	
3		scrubber drying direct method	<input type="checkbox"/>	Ecofloor Reshine Libero	0.5 - 1% 1 - 2% 0.5 - 3%	 Microsol fibre pad/  Pad red/ S  Scrubbing brush PP/	Duomatic / Laser Sprinter / iMatic Mambo / Samba	
Schutzbehandlung ohne Porenf								
3		wet mopping direct method	<input type="checkbox"/>	Redur Brill	1% 1 - 2%	Mop Microbrush/ Micro-Mop Top/ Flat mop/	Wetbox system Socar / Drewell Variwet / B. Varifix	Brill should be used with flat mop only
3		scrubber drying direct method	<input type="checkbox"/>	Redur Brill	1% 1 - 2%	 Microsol fibre pad/  Pad red/ S  Scrubbing brush PP/	Duomatic / Laser Sprinter / iMatic Mambo / Samba	

* basic treatment / structure: B: coated / C: waxed / D: oiled / E: sealed / F: untreated / G: maintenance care product / P: polishing / S: structured / V: heavily soiled

General instructions for cleaning and care

no. 40 Cement surface layer (rough)



interim cleaning

object _____

date _____



















address _____

customer _____

work process: select one work stage from each number

room classification _____

representative _____

↓	cleaning method		frequency	recommendations chemical products	dosage	* recommendations pad / brush / mop / cloth	recommendations machine / tool	comments
1		dusting damp mopping	<input type="checkbox"/>			B B Masslinn 2000/Floorwit white Synthetic fur	Balit Varifix/ Balit/	
1		dry vacuum cleaning	<input type="checkbox"/>			Dust roller nozzle	Monovac / Scuba	
1		vacuum sweeping sweeping	<input type="checkbox"/>			Carpet set - Twister	Speedmatic Twister Turbo Sweep	large areas: 
2		chewing gum removal	<input type="checkbox"/>	Karpfrost Karpotek	100%		Monovac / Scuba	if needed 
cleaning without maintenance								
3		wet mopping indirect method	<input type="checkbox"/>	Reshine G Rewit 2000	3 - 5% 2 - 5%	Micro-Mop Top/ Mop Microbrush/	Wetbox system Socar / Drewell	 
3		scrubber drying indirect method	<input type="checkbox"/>	Reshine G Rewit 2000	3 - 5% 2 - 5%	 Microsol fibre pad/  Pad blue/ S  Scrubbing brush PP/	Duomatic / Laser Mambo / Samba Sprinter / iMatic	 
5		wet mopping direct method	<input type="checkbox"/>	Biosan	3%	Micro-Mop Top/ Microsol mop/	Socar / Drewell	if needed, bad smell could be removed with  

* basic treatment / structure: B: coated / C: waxed / D: oiled / E: sealed / F: untreated / G: maintenance care product / P: polishing / S: structured / V: heavily soiled

important: For initial cleaning after interim cleaning, see "initial cleaning".

General instructions for cleaning and care

no. 40 Cement surface layer (rough)



basic cleaning

object _____

date _____


















address _____

customer _____

work process: select one work stage from each number

room classification _____

representative _____

	cleaning method	frequency	* recommendations chemical products	dosage	* recommendations pad / brush / mop / cloth	recommendations machine / tool	comments
1	 dusting  damp mopping	<input type="checkbox"/>			B Masslinn 2000/Floorwit white B Synthetic fur	Balit Varifix/ Balit/	
1	 dry vacuum cleaning	<input type="checkbox"/>			S Dust roller nozzle	Monovac / Scuba	
1	 vacuum sweeping sweeping	<input type="checkbox"/>			Carpet set - Twister	Speedmatic Twister Turbo Sweep	large areas: <input type="checkbox"/> 2 m
2	 chewing gum removal	<input type="checkbox"/>	Karpotek Karpfrost	100%		Monovac / Scuba	if needed <input type="checkbox"/>
cleaning without maintenance							
3	 wet scrubbing and wet vacuuming	<input type="checkbox"/>	Antiwax forte G Rewit 2000 B Relino	30 - 50% 10 - 20% 20 - 50%	⊙ Scrubbing brush Supernylon ⊙ Scrubbing brush washbeton/ B ● Pad green/	Monomatic I / Watertank Duovac /	<input type="checkbox"/> <input type="checkbox"/>  
3	 scrubber drying indirect method	<input type="checkbox"/>	Antiwax forte G Rewit 2000 B Relino	30 - 50% 10 - 20% 20 - 50%	⊙ Scrubbing brush Supernylon V ● Scrubbing brush Tynex/ B ● Pad green/	Duomatic / Laser Mambo / Samba Sprinter / iMatic	<input type="checkbox"/> 2 m <input type="checkbox"/> <input type="checkbox"/>  
4	rinsing   	<input type="checkbox"/>	pure water		S ⊙ Microsol fibre pad/ ⊙ Scrubbing brush Supernylon/	Monomatic I / Watertank Duovac /	<input type="checkbox"/> pH 7 
5	 wet mopping direct method	<input type="checkbox"/>	Biosan	3%	Micro-Mop Top/ Microsol mop/	Socar / Drewell	if needed, bad smell could be removed with <input type="checkbox"/> 

* basic treatment / structure: B: coated / C: waxed / D: oiled / E: sealed / F: untreated / G: maintenance care product / P: polishing / S: structured / V: heavily soiled

important:

change pad often

Use a coin or a key to do a scratch test, to check if all the protective coating has been removed.

When white abrasion occurs, carry out a full clean to remove all the protective coating

General instructions for cleaning and care

no. 40  Cement surface layer (rough)



protective treatment

object _____

date _____
















address _____

customer _____

work process: select one work stage from each number

room classification _____

representative _____

cleaning method		* recommendations chemical products	dosage	* recommendations pad / brush / mop / cloth	recommendations machine / tool	comments
1	 dusting damp mopping			Masslinn 2000/Floorwit white Synthetic fur	Balit Varifix/ Balit/	
1	 dry vacuum cleaning			Dust roller nozzle	Monovac / Scuba	
pore filling (only if necessary)						
2	 pore filling	F Porosol	100%	Cover for Florfix Flat mop/ Multi squeegee/	Florfix/ Drewell/	If necessary, one layer on porous surface  
coating						
3	 coating	Stoner Mepol HM	100% 100%	Cover for Florfix Flat mop/	Florfix/ Drewell/	1 - 3 thin layers  
3	 waxing	Polish	100%	Cover for Florfix Flat mop/	Florfix/ Drewell/	1 - 3 thin layers  
4	 dusting damp mopping			Masslinn 2000/Floorwit white Synthetic fur	Balit Varifix/ Balit/	if needed
coating						
2	 impregnation	F Imprasol	100%	Cover for Florfix Flat mop/	Florfix/ Drewell/	apply first layer with care  

* basic treatment / structure: B: coated / C: waxed / D: oiled / E: sealed / F: untreated / G: maintenance care product / P: polishing / S: structured / V: heavily soiled

important:

if needed

before protective treatment: the floor must be perfectly stripped, thoroughly rinsed and completely dry!

Process treatment of protection: see description of method

do not coat impregnated floors

For initial cleaning with maintenance cleaner after protective treatment, see "initial cleaning".

General instructions for cleaning and care

no. 40 Cement surface layer (rough)



Information about the flooring



Wetrok AG cannot accept any liability for damages due to improper use.
For security information, see the safety data sheet at www.wetrok.ch.
Wear protection: gloves, safety goggles, work clothes
Follow the information and remarks on the label, product data sheet and material safety data sheet.
The product data sheet describes the product and gives information about its application, storage. See www.wetrok.ch
The recommended colours of pad and brushes consist to the actual wWetrok product range
Follow the special cleaning and care instructions of the floor manufacturer
The cleaning and care instructions are recommendations and suggestions and apply to floorings in object quality.



Do not coat structured floor coverings.
Strong acids and abrasive pads and brushes can destroy limestone and cement-bonded artificial stone.
Cement floors are sensitive to strong acids and strongly alkaline cleaners.
Do not use maintenance and protection products in wet areas. Danger of slipping!



Cement mortar consists of Portland cement and sand.
Cement coatings are painted with special concrete paints and treated with concrete sealants.

Distinguishing feature: cement-bound synthetic stone acid assay: apply a little basic sanitary cleaner to the magnesite covering. Foams up: material damage!



Remove loose dirt before every cleaning, damp mop smooth floors and vacuum structured floors.
Cleaning agents and surface treatments may alter the appearance and properties of a floor's surface.
Test on an inconspicuous spot to find which product is suitable for your requirements.
Test beforehand on an inconspicuous spot to see if the cleaning agent or surface treatment damages the floor.
Dirt-trapping zones, incl. dirt-trapping mats (Wetrok Gardamat) in the entrance, at least 7m long, greatly reduce the amount of dirt tracked into the building.

If you have any questions, please don't hesitate to contact us.
For training courses, contact the Wetrok Academy, tel. +41 (0)43 255 51 43 or academy@wetrok.ch.

Wetrok AG Steinackerstrasse 62, CH-8302 Kloten, Tel +41 (0)43 255 51 51, info@wetrok.ch, www.wetrok.ch, www.wetrok.com